



Motorized Film Drive and Unmanned Photography



- 1 Motor Drive MA
- 2 Power Winder A
- 3 Power Winder A2
- 4 Ni-Cd Charger MA
- 5 Ni-Cd Pack MA
- 6 Battery Pack MA
- 7 Battery Magazine MA
- 8 Extension Cord E 1000
- 9 Wireless Controller LC-1
- 10 Remote Switch 60
- 11 Remote Switch 3
- 12 Time Lapse Programmer A Unit
- 13 Time Lapse Programmer B Unit

Canon
<http://www.camera.canon.com.my>

Motor Drive, Winder and Flash System



Flash Photography

- 1 Speedlite 011A
- 2 Speedlite 133A
- 3 Speedlite 155A
- 4 Speedlite 166A
- 5 Speedlite 177A
- 6 Speedlite 188A
- 7 Speedlite 199A
- 8 Macrolite ML-1
- 9 Sensor Unit G 100
- 10 Sensor Unit G20
- 11 Speedlite 533G
- 12 Speedlite 577G
- 13 Transistor Pack G