

ACCESSORIES

LENS

C21-5291	Fish-Eye EF 15mm f/2.8
C21-5301	EF 24mm f/2.8
C21-5281	EF 28mm f/2.8
C21-6211	EF 50mm f/1.8
C21-7261	Softfocus EF 135mm f/2.8
C21-8272	EF 200mm f/1.8 L (Ultrasonic)
C21-8252	EF 300mm f/2.8 L (Ultrasonic)
C21-8292	EF 600mm f/4 L (Ultrasonic)
C21-9422	EF 28—70mm f/3.5—4.5II
C21-9482	EF 28—80mm f/2.8—4 L (Ultrasonic)
C21-9411	EF 35—70mm f/3.5—4.5
C21-9412	EF 35—70mm f/3.5—4.5 A
C21-9401	EF 35—105mm f/3.5—4.5
C21-9461	EF 35—135mm f/3.5—4.5
C21-9451	EF 50—200mm f/3.5—4.5
C21-9452	EF 50—200mm f/3.5—4.5 L
C21-9441	EF 70—210mm f/4.0
C21-9492	EF 100—200mm f/4.5 A
C21-9431	EF 100—300mm f/5.6
C21-9432	EF 100—300mm f/5.6 L
C26-1191	EF 50mm f/2.5 Compact-Macro
C54-3781	Extender EF 2X
C54-3801	Extender EF 1.4X
C54-3791	Life-size Converter EF

FLASH ACCESSORIES

C50-0641	Speedlite 160E
C50-0552	Speedlite 420EZ
C50-0561	Speedlite 300EZ
C50-1632	TTL Hot Shoe Adapter 2

VIEWFINDER ACCESSORIES

C50-9061	Eyecup Eb
C50-5111-001	Dioptric Adjustment Lens E (+ 3)

C50-5111-011	Dioptric Adjustment Lens E (+ 3) w/Frame
C50-5112-001	Dioptric Adjustment Lens E (+ 2)
C50-5112-011	Dioptric Adjustment Lens E (+ 2) w/Frame
C50-5113-001	Dioptric Adjustment Lens E (+ 1.5)
C50-5113-011	Dioptric Adjustment Lens E (+ 1.5) w/Frame
C50-5114-001	Dioptric Adjustment Lens E (+ 1)
C50-5114-011	Dioptric Adjustment Lens E (+ 1) w/Frame
C50-5115-001	Dioptric Adjustment Lens E (+ 0.5)
C50-5115-011	Dioptric Adjustment Lens E (+ 0.5) w/Frame
C50-5121-001	Dioptric Adjustment Lens E (0)
C50-5121-011	Dioptric Adjustment Lens E (0) w/Frame
C50-5122-001	Dioptric Adjustment Lens E (− 0.5)
C50-5122-011	Dioptric Adjustment Lens E (− 0.5) w/Frame
C50-5123-001	Dioptric Adjustment Lens E (− 2)
C50-5123-011	Dioptric Adjustment Lens E (− 2) w/Frame
C50-5124-001	Dioptric Adjustment Lens E (− 3)
C50-5124-011	Dioptric Adjustment Lens E (− 3) w/Frame
C50-5125-001	Dioptric Adjustment Lens E (− 4)
C50-5125-011	Dioptric Adjustment Lens E (− 4) w/Frame

FILTERS

C43-0401	Circular Polarizing Filter PL-C (52mm diameter)
C43-0402	Circular Polarizing Filter PL-C (58mm diameter)
C43-0404	Circular Polarizing Filter PL-C (72mm diameter)
C43-0405	Circular Polarizing Filter PL-C (48mm diameter)

CASES

C46-1461	Semi-hard Case for EOS 750/850 S (with EF 50mm f/1.8)
C46-1462	Semi-hard Case for EOS 750/850 L (with EF 35—70mm f/3.5—4.5)
C46-1463	Semi-hard Case for EOS 750/850 LL (with EF 35—105mm f/3.5—4.5)
C46-1401	Snap Case SA-4
C46-1402	Snap Case SB-4
C47-1121	Lens Case ES-C9
C47-1131	Lens Case ES-C13
C47-1141	Lens Case ES-C17
C47-1151	Lens Case ES-C20
C49-0711	Soft Case for Speedlite 160E
C49-0671	Soft Case for Speedlite 420EZ
C49-0681	Soft Case for Speedlite 300EZ

DUST CAPS

C45-5402	Lens Dust Cap E
C45-5201	Lens Dust Cap E-52
C45-5803	Lens Dust Cap E-58
C45-7202	Lens Dust Cap E-72
C45-2051	Camera Cover RF-3

LENS HOOD

C44-6203	Hood ET-62
C44-6503	Hood ES-65
C44-6504	Hood EW-65
C44-6505	Hood ET-65
C44-6801	Hood EW-68B
C44-6802	Hood EW-68A
C44-7901	Hood ES-79

INTERCHANGEABLE GRIP

C51-9961	Grip GR 50
----------	------------