


## Minolta 7000 System Accessories



## MINOLTA 7000 SYSTEM

1. Cable CD
2. Cable EX
3. Cable OC
4. Off-Camera Shoe
5. Triple Connector TC-1000
6. AC Adapter AC-1000
7. Panel Set PS-1000
8. Bounce Reflector Set
9. Wideangle Adapter
10. AF Illuminator Unit AI-1000
11. Grip Extension Cable EC-1000
12. Battery Cartridge PG
13. Ni-Cd Battery Pack NP-2
14. Ni-Cd Charger QC-1
15. Eyepiece Hood EH-7
16. Eyepiece Cap
17. Magnifier VN

18. Angle Finder V<sub>N</sub>
19. Eyepiece Corrector 1000
20. Focusing Screens
21. Ni-Cd Charger NC-2
22. Battery Holder BH-70S
23. Battery Holder BH-70L
24. External Battery Pack EP-70
25. Remote Cord RC-1000L
26. Remote Cord RC-1000S
27. AF 24mm f/2.8
28. AF 28mm f/2.8
29. AF 50mm f/1.7
30. AF 50mm f/1.4
31. AF 135mm f/2.8
32. AF 300mm f/2.8 Apo
33. AF 28—85mm f/3.5—4.5
34. AF 28—135mm f/4—4.5

35. AF 35—70mm f/4
36. AF 35—105mm f/3.5—4.5
37. AF 70—210mm f/4
38. AF 50mm f/2.8 Macro
39. Filters
40. Portrayer Filters
41. Close Up Lens
42. Gelatin-Filter Holder
43. Body Cap
44. Lens Cap
45. Lens Rear Cap
46. Panorama Head II
47. Lens Case
48. Camera Case
49. Mini Tripod TR-1
50. Copy Stand II

## METERS & ACCESSORIES

1. Spotmeter M
2. Auto Meter III F
3. Auto Meter III
4. Flash Meter III
5. Color Meter II
6. Booster II
7. 4X&8X Spherical ND Diffuser
8. Flat Diffuser
9. Spot Mask II
10. Reflected-light Attachment
11. Mini Receptor
12. Sync Cord II