



※When the Auto Bellows PC is used with the CONTAX S2/S2b, the connector cord is not required. Use a double, mechanical cable release available on the market.