
The Nikon F3 (DE-2 Eye level and DE-3 High Eye Point Finders)














- 1 Shutter-speed dial locking button
- 2 Depth-of-field preview button
- Mirror lockup lever
- (4) Neckstrap eyelet
- (5) Self-timer LED
- 6 Backup mechanical release lever
- (7) Expose memory lock button
- B Lens mounting flange
- Reflex mirror

(10) Motor drive coupling (11) Motor drive positioning hole 12) Film rewind button (13) Memo holder (14) ADR window (15) Film rewind knob [16] ASA/ISO film speed/Exposure compensation dial (17) Sync terminal (18) Lens mounting index (19) Lens release button (20) Meter coupling lever release button (21) Meter coupling lever (22) Viewfinder illuminator (23) Tripod/Motor drive coupling socket (24) Motor drive electrical contacts (25) Battery chamber lid (26) Motor drivecoupling cover (27) Depth-of-field indicators/Mounting ring (28) Focusing ring (29) Aperture ring (30) Meter coupling ridge


(31) Finder mounting/release levers

(32) Exposure compensation scale

(33) Exposure compensation index

(34) Film rewind crank

Hot-shoe contacts



(51) Power switch

(52) Multiple exposure lever

(53) Shutter release button

Frame counter

(55) Film advance lever

[57] Shutter speed dial

Shutter-speed scale

Film plane indicator

The headquater of Nikon Corporation has a section detailing how to request for their Instruction Manual of various optical products, the URL is here: http://www.nikon.co.jp/main/eng/faq-impe.htm

^{*} Credit: Shiro Malaysia, local distributor for Nikon Optical Products for providing this info, some parts of the manual was modified slighly to suit the PDF format.

Information in this site was merely created for your quick reference. We strongly suggest you write to Nikon corporation for actual copy of the official manual.

The tradenames of "Nikon" and the logo is a registered trademark of Nikon Corporation, Japan.