
IMPORTANT!

The camera body you have purchased is packaged separately from the lens. Before mounting the lens, check if it is capable of Automatic Maximum Aperture Indexing (AI) operation with your camera body by verifying that the lens' aperture ring is fitted with a meter coupling ridge as illustrated at the right. Note that the "Ai" mark on the cover of the instruction sheet provided with AI Nikkor lenses is your assurance that the lens offers the AI feature.

If the lens is fitted with the mirror coupling ridge, it is fully capable of full aperture exposure measurement and automatic maximum aperture indexing; to attach it to the camera, follow the directions provided in the BASIC OPERATION section of this instruction manual.

If the lens is non-AI, stop-down exposure measurement is required with the camera body's meter coupling lever locked up: to lock up the lever, follow the directions in the "Meter coupling lever" section of CONTROLS IN DETAIL.



^{*} Credit: Shiro Malaysia, local distributor for Nikon Optical Products for providing this info, some parts of the manual

was modified slighly to suit the PDF format.

The headquater of Nikon Corporation has a section detailing how to request for their Instruction Manual of various optical products, the URL is here: http://www.nikon.co.jp/main/eng/faq-impe.htm Information in this site was merely created for your quick reference. We strongly suggest you write to Nikon corporation for actual copy of the official manual.

The tradenames of "Nikon" and the logo is a registered trademark of Nikon Corporation, Japan.